

Start Guide

M56S EtherCAT Servo Motor CiA402 PP Mode (1-axis)



86Duino Coding IDE 501

EtherCAT Library

(Version 1.0)

Revision


Date	Version	Description
2025/05/29	Version1.0	New Release.

Preface

In this guide, we will show you how to use the EtherCAT MDevice QEC-M-01 and the Moon’s M56S EtherCAT Servo Motor.

Notes QEC’s PoE (Power over Ethernet)

In QEC product installations, users can easily distinguish between PoE and non-PoE: if the RJ45 house is red, it is PoE type, and if the RJ45 house is black, it is non-PoE type.



PoE (Power over Ethernet) is a function that delivers power over the network. QEC can be equipped with an optional PoE function to reduce cabling. In practice, PoE is selected based on system equipment, so please pay attention to the following points while evaluating and testing:

- 1. The PoE function of QEC is different and incompatible with EtherCAT P, and the PoE function of QEC is based on PoE Type B, and the pin functions are as follows:




- 2. When connecting PoE and non-PoE devices, make sure to disconnect Ethernet cables at pins 4, 5, 7, and 8 (e.g., when a PoE-supported QEC EtherCAT MDevice connects with a third-party EtherCAT SubDevice).
- 3. QEC’s PoE power supply is up to 24V/3A.

1. Connection and wiring hardware

The following devices are used here:


1. QEC-M-01 (EtherCAT MDevice)
2. M56S (EtherCAT Servo Motor)
3. 24V power supply & EU-type terminal cable & LAN cable
4. 220V/400V AC input



1.1 QEC-M-01


QEC EtherCAT MDevice.

1. Power Supply: Connect to Vs+/Vs- and Vp+/Vp- power supplies via EU terminals for 24V power.
2. EtherCAT Connection: Using the EtherCAT Out port (On the top side) connected to the EtherCAT In port of EtherCAT SubDevice via RJ45 cable.



1.2 M56S

M56S series is a new generation of high-end 220V/400V AC input servo system, the power range is from 50W to 7.5KW. The drive adopts advanced motion control algorithms, coupled with a 26-bit high precision encoder motor, the velocity loop bandwidth is up to 3.5KHz. Efficient automatically adjusts the loop gain, superior vibration suppression and external disturbance compensation performance. The drive supports full closed-loop control, built-in regenerative energy absorption resistor, STO safety function and dynamic braking module (for certain models). It supports the control mode of position, velocity, torque and Q programming.




M56S Driver Wiring Overview

- **Power Supply**
 - AC input split into:
- **Communication**
 - CN6 / CN7: EtherCAT connection to QEC-M-01.
- **I/O Control**
 - CN2: Built-in I/O port.

- Connects to PLC or motion controller.
 - For start, stop, alarm reset, etc.
- **Encoder Feedback**
 - CN3: Main encoder (supports 21/26-bit absolute encoders).
 - CN4: Second encoder input for full-closed loop.
- **Front Panel**
 - LED Display: Shows status and alarms.
 - Function Keys: For parameter setting.

2. Software/Development Environment

Download 86duino IDE from <https://www.qec.tw/software/>.



86duino Coding IDE 501

The new major release of the 86duino IDE 501 is faster and more powerful than ever! It now supports a broader range of third-party EtherCAT sub-devices and introduces additional EthercatDevice classes, including a generic CiA 402 EtherCAT slave class designed to control any EtherCAT servo drive compliant with the CiA 402 standard.

Windows (ZIP file)

Date: 2024.12.06

Download

After downloading, please unzip the downloaded zip file, no additional software installation is required, just double-click 86duino.exe to start the IDE.



Note:

If Windows displays a warning, click Details once and then click the Continue Run button once.



86duino Coding IDE 501+ looks like below.





3. Connect to PC and set up the environment

Follow the steps below to set up the environment:

1. Connect the QEC-M-01 to your PC via a Micro USB to USB cable (86Duino IDE installed).
2. Turn on the QEC power.
3. Open "Device Manager" (select in the menu after pressing Win+X) -> "Ports (COM & LPT)" in your PC and expand the ports; you should see that the "Prolific PL2303GC USB Serial COM Port (COMx)" is detected; if not, you will need to install the required drivers.
(For Windows PL2303 driver, you can download [here](#))



4. Open the 86Duino IDE.
5. Select the correct board: In the IDE's menu, select Tools> Board > QEC-M-01 (or the QEC MDevice model you use).
6. Select Port: In the IDE's menu, select Tools > Port and select the USB port to connect to the QEC MDevice (in this case, COM9 (QEC)).



4. Write code

The EtherCAT MDevice (QEC-M-01) and the Moon's M56S (EtherCAT Servo Motor) can be configured and programmed via the EtherCAT library in the 86Duino IDE.

The Arduino development environment has two main parts: `setup()` and `loop()`, which correspond to initialization and main programs. Before operating the EtherCAT network, you must configure it once. The process should be from Pre-OP to OP mode in EtherCAT devices.

The following program sets the M56S into CiA402 Profile Position (PP) mode:

- EtherCAT Cycle Time: 1 millisecond.
- EtherCAT Mode: ECAT_SYNC.

The `EthercatMaster` object ("mdevice") represents the QEC-M-01, while the `EthercatDevice_CiA402` object ("motor") represents the M56S.

A. In Setup Function:

In the `setup()` function initializes communication and configures the motor for CiA402 Profile Position (PP) mode. Follow the steps below:

1. Initialize Serial Communication
 - Start serial communication at a baud rate of 115200.
2. Start the EtherCAT MDevice
 - Begin the EtherCAT MDevice and set the EtherCAT state machine to the PRE-OPERATIONAL state.
3. Start the EtherCAT MDevice
 - Use the `start()` function to switch the EtherCAT state machine to the OPERATIONAL state. Set the cycle time to 1ms and ECAT_SYNC mode.
4. Set Profile Position (PP) Mode
 - Configure the motor to PP mode using `setCiA402Mode(CIA402_PP_MODE)`.
5. Enable the Motor
 - Use the `enable()` function to enable the motor and transition it to CIA402_OPERATION_ENABLED.
6. Configure Profile Parameters
 - Motion Profile Type: Linear Ramp, Profile Velocity: 100,000, Acceleration: 5,000, Deceleration: 5,000.

B. In Loop Function:

In the `loop()` function, the current position of the motor is displayed on the Serial Monitor, and the motor alternates its movement back and forth in a repeating cycle:

1. State Machine Logic
 - case 0: Start the motor and move to the target position (100,000 units). Once the command is successfully executed, transition to the next state.

- case 1: Wait for the motor to reach the target position. Once the target is reached, proceed to the next state.
- case 2: Start the motor and move back to the original position (-100,000 units). Once the command is successfully executed, transition to the next state.
- case 3: Wait for the motor to return to the original position. Once the target is reached, reset the state machine back to case 0 to repeat the movement cycle.

2. Code Logic Summary

- Use the `pp_Run()` function to initiate position movement.
- Use the `pp_IsTargetReached()` function to confirm whether the target position has been reached.
- The state machine starts at case 0 and resets after completing case 3.

The example code is as follows:

```
#include "Ethercat.h"

EthercatMaster mdevice;
EthercatDevice_CiA402 motor;

int pp_state = 0;

void setup() {
  Serial.begin(115200);
  while (!Serial);

  Serial.print("Begin: "); Serial.println(mdevice.begin());
  Serial.print("Slave: "); Serial.println(motor.attach(0, mdevice));
  Serial.print("Start: "); Serial.println(mdevice.start(1000000, ECAT_SYNC));

  motor.setCiA402Mode(CIA402_PP_MODE);
  Serial.print("Enable: "); Serial.println(motor.enable());
  motor.pp_SetMotionProfileType(0); // Linear ramp (trapezoidal profile)
  motor.pp_SetVelocity(100000);
  motor.pp_SetAcceleration(5000);
  motor.pp_SetDeceleration(5000);
}



void loop() {
  Serial.print("Pos: "); Serial.println(motor.getPositionActualValue());
  switch (pp_state)
  {
    case 0:
      if (motor.pp_Run(100000) == 0)
```


```



    pp_state++;
    break;
case 1:
    if (motor.pp_IsTargetReached())
        pp_state++;
    break;
case 2:
    if (motor.pp_Run(-100000) == 0)
        pp_state++;
    break;
case 3:
    if (motor.pp_IsTargetReached())
        pp_state = 0;
    break;
}
}

```

Note:

Once the code is written, click on the toolbar to  compile, and to confirm that the compilation is complete and error-free, you can click  to upload.





Troubleshooting

QEC-M-01 cannot successfully upload code

When you are unable to successfully upload code, please open 86EVA to check if your QEC EtherCAT MDevice's environment is abnormal. As shown in the figure below, please try updating your QEC EtherCAT MDevice's environment, which will include the following three items: Bootloader, EtherCAT firmware, and EtherCAT tool.



Now, we will further explain how to proceed with the update:


Step 1: Setting up QEC-M

1. Download and install 86Duino IDE 500+ (or a newer version): You can download it from [Software](#).
2. Connect the QEC-M: Use a USB cable to connect the QEC-M to your computer.
3. Open 86Duino IDE: After the installation is complete, open the 86Duino IDE software.
4. Select Board: From the IDE menu, choose "Tools" > "Board" > "QEC-M-01" (or the specific model of QEC-M you are using).
5. Select Port: From the IDE menu, choose "Tools" > "Port" and select the USB port to which the QEC-M is connected.


Step 2: Click “Burn Bootloader” button

After connecting to your QEC-M product, go to “Tools”> “Burn Bootloader”. The currently selected QEC-M name will appear. Clicking on it will start the update process, which will take approximately 5-20 minutes.

QEC-M-01:



Step 3: Complete the Update



After completing the above steps, your QEC-M has been successfully updated to the latest version of the development environment.

Warranty

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster. Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, originality to use this product. Vendor will not be liable for any claim made by any other related party. Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

All Trademarks appearing in this manuscript are registered trademark of their respective owners. All Specifications are subject to change without notice.

©ICOP Technology Inc. 2025